

# FORMAX<sup>®</sup>

---

Atlas-TRIO15  
Multi-Function Slitter/Creaser/Cutter

## Contents

1. Installation .....	4
1- (1)Installation .....	4
1- (2)Installing options .....	8
2. General instruction .....	11
3. Touch panel operation .....	15
3- (1) SERVICE MENU .....	15
3- (2) MANUAL OPERATION Screen .....	17
3- (3) SPEED Screen .....	18
3- (4) INPUT DATA CHECK Screen .....	18
3- (5) LANGUAGE Screen .....	22
3- (6) MAINTENANCE Screen .....	23
4. Paper jam .....	24
5. Replacement of parts .....	26
5- (1) Slitter Unit .....	26
5- (2) Guillotine Unit .....	29
5- (3) Feed belt unit .....	30
6. Adjustment .....	32
6- (1) Feed settings .....	32
6- (2) Cut mark sensor .....	40
6- (3) PCB setting .....	41
6- (4) Accuracy adjustment .....	42
7. How to make layout .....	43
7- (1) General template(mm) .....	43
7- (2) General template(inch) .....	44
8. Electricity related .....	45
8- (1) Equipment, Electric circuit, and parts .....	45
8- (2) Board Details .....	48
8- (3) Input/Output LED Details .....	50
8- (4) Tap Voltage Details .....	53
8- (5) Wiring Details .....	54
9. Program update .....	56
9- (1) Software install .....	56
9- (2) Touch panel .....	63
9- (3) CPU board .....	66
10. Cleaning & greasing .....	72
11. Recommended replacement parts .....	74
12. Troubleshooting .....	75




# 1. Installation

## 1- (1)Installation


### (a) Fixing screw

The fixing screws shown on below images must be removed before use.




### (b) Caster

Please be sure to lock a caster brake.




(c) Feed table




(d) Stacker and Waste box

- ① Place the Waste box under the Chute.




- ② Open the stacker and set the stays in the indentation of the back of the stacker at an appropriate angle to allow smooth paper ejection.


- ③ Adjust the large paper guide according to the paper size.




- ④ Hang the business card stacker to the Stacker panel.  
 ⑤ Find the V- notch to see where to put the business card partition.  
 ⑥ When it is not used, it may be hooked to the upper holes in the stacker panel.



- ⑦ Change the settings of the stacker according to the cut pattern.




(e) Electric-power




## 1- (2)Installing options

### (a) Long stacker

Loosen the screw to remove the standard stacker, attach the long stacker and tighten the screw.




Stacker can be extended by pulling an extension with pulling a lock knob.






**(b) Long Feed Table**

Loosen the screws, remove the standard feed table. Attach the long feed table and tighten the screws.




Adjust the large paper guide according to the paper size.





## 2. General instruction

(a) Caution



(b) Necessary tools

- C-clip ring pliers



For replacing slitter blades

- Maintenance kit

Pipe  
(For slitters)



For replacing slitter blades

Program update tool




- Feeler gauge





For clutch

(c) Factory setting



Factory setting sheet is attached inside of the front cover.



(d) Remove covers






(e) Names of parts




### 3. Touch panel operation


#### 3- (1) SERVICE MENU




Press and hold the bottom left corner of the screen for 3 seconds.



Press and hold the top left corner of the screen for 3 seconds.




Enter the service password.







### 3- (2) MANUAL OPERATION Screen



- ① Carrying roller will rotate.
- ② Carrying roller will rotate. (Continuous)
- ③ The speed of Carrying roller can be adjusted to two levels (SLOW or FAST).
- ④ Carrying rollers will rotate at input length. [mm]
- ⑤ Enter the dimension of Fixed feed.
- ⑥ FEED TABLE will move downward while this is being pressed.
- ⑦ FEED TABLE will move upward while this is being pressed.
- ⑧ Vacuum motor will be turned ON and OFF.
- ⑨ Blow motor will be turned ON and OFF.
- ⑩ Guillotine will move once.
- ⑪ Crease will move upper limit.
- ⑫ Crease will move lower limit.
- ⑬ Go to SPEED screen.
- ⑭ Reset the counter for servo movement to zero.
- ⑮ Counter for servo movement.
- ⑯ Stop all operations. Of note, Cutter and Crease will move to the upper limit.
- ⑰ Go to INPUT DATA CHECK screen.
- ⑱ Double Feed Detection


Transmittance of the double feed sensor is shown as an integer between 0 and 1023. The number 1023 represents the state in which there is no sheet under the sensor, while the number closer to zero indicates that thicker sheets have been detected by the sensor.

 : paper sheets are being loaded.

 : no paper sheets loaded.


- ⑲ Return to SERVICE MENU Screen.

### 3- (3) SPEED Screen



- ① Regarding suction adjustment and speed change, refer to “5.1 Adjustments on the paper feed section” in Operation Manual.

### 3- (4) INPUT DATA CHECK Screen



#### ① PPR L/EDGE SENS 1 (Origin sensor)

The sensor lamp will be turned off when shielded and turned on when transmitted.

The lamp on the screen will be turned on when shielded and turned off when transmitted.



#### ② C/MARK SENS (Cut mark sensor)

The sensor lamp (orange) will be turned on when detecting black color and turned off with no detection.

The lamp on the screen will be turned on when detecting black color and turned off with no detection.


How to adjust. (👉 Page40)



③ PPR L/EDGE SENS 2 (Stop sensor)

The sensor lamp will be turned on when shielded and turned off when transmitted.

The lamp on the screen will be turned on when shielded and turned off when transmitted.





④ CUTTER UP/LMT SW

The lamp on the screen will be turned on when the switch is on.




⑤ COVER SENS A, B

The sensor lamp will be turned off when shielded and turned on when transmitted. The lamp on the screen will be turned off when shielded and turned on when transmitted.



⑥ TBL LW/LMT SW


The lamp on the screen will be turned on when switched on.



⑦ FD TBL UP/SENS


The sensor lamp will be turned off when shielded and turned on when transmitted.

The lamp on the screen will be turned off when shielded and turned on when transmitted.




⑧ DOUBLE FEED SENSOR

The lamp on the screen will be turned off when shielded and turned on when transmitted.



⑨ INPUT SENS

The lamp on the screen will be turned on when shielded and turned off when transmitted.



⑩ SERVO ALERT

The lamp will be turned on if an error occurs on the servo motor; the lamp stays off when no error condition exists.

⑪ SERVO POSITIONED


The lamp stays on while the servo motor is not running and stays off while the motor is running.

⑫ CRSR UP/SENS

⑬ CRSR LW/SENS

The sensor lamp will be turned off when shielded and turned on when transmitted.

The lamp on the screen will be turned off when shielded and turned on when transmitted.



⑭ CONVEYER CONNECT

The lamp on the screen turns on when the harness is connected to the machine. It turns off when the harness is disconnected.



⑮ CONVEYER SENS


The lamp on the screen will be turned off when shielded and turned on when transmitted.



⑯ RETURN

Return to Manual Operation Screen.

### 3- (5) LANGUAGE Screen




#### ① Language

Select an appropriate language. The language of the touch panel will switch on. **English** is selected at the time of shipment.

#### ② RETURN

Return to Service menu Screen.

### 3- (6) MAINTENANCE Screen




- ① Distance between guillotine and creaser. [mm]
- ② Distance between stop sensor and guillotine. [mm]
- ③ Distance between origin sensor and Cutmark sensor. [mm]
- ④ Distance between origin sensor and guillotine. [mm]
- ⑤ The number of times that the machine checks double-feed. [times]
- ⑥ This is the time when the paper feed table goes down. [times]
- ⑦ Total number of processed Guillotine. [times]
- ⑧ Total number of processed Crease. [times]
- ⑨ Total number of processed paper. [sheets]
- ⑩ Operation time of Feed table. [hours : minutes]
- ⑪ This is to select either Conveyor or AutoFold as an External interface.
- ⑫ This is to set either mm or inch as the measurement input unit.
- ⑬ Return to Service menu Screen.

## 4. Paper jam


- ① Enter MANUAL CONTROL screen, press < > buttons to inch the rollers forward/backward and remove the jammed paper.

If paper is stuck around the guillotine section, press CUTTER to cycle the guillotine to chop jammed paper.

MANUAL CONTROL screen




- ② Detach Sponge roller and Slitter cover if necessary, and remove jammed paper.





Note.


Do not attach Slitter cover on Washer and Screw. This may cause paper jam.



Washer & screw

Note.


Remove paper in waste box before the waste bin becomes full. It may cause paper strips remain inside the machine and cause paper jam.



Note.

If paper jam often occurs, make sure that paper strip is not left in the indicated sections.


- Inside of Slitter head
- Inside of Guillotine cover
- Inside of Crease



## 5. Replacement of parts


### 5- (1) Slitter Unit

- ① Remove Slitter cover.




Back side

- ② Loosen 7screws. (Not remove)
- ③ Remove 1screw.
- ④ Remove pulley and Retaining ring-E.




Front side

- ⑤ Loosen 2screws and remove cover.
- ⑥ Remove hexagonal shafts.
- ⑦ Remove 1screw.




- ⑧ Pull Slitter Units out.

Shaft might get rusty if touched by bare hands.



Note.



When removing the shaft from the slitter head, ensure not to lose the set piece.



Note.





When fixing a slitter blade on a Margin slitter, fix the screws with pressing the Upper slitter lid towards arrowed direction.

This moves the contact point of the Upper blade and Lower blade, and improves cutting quality.




### 5- (2) Guillotine Unit

- ① Check if the locating metal plate is in contact with the cutter unit.  
This will be a mark for reattachment.
- ② Remove screws and Guillotine Cover.
- ③ Remove screws and pull Guillotine Unit out.




### 5- (3) Feed belt unit


- ① Remove screws and cover.




- ② Disconnect the harness.



- ③ Remove clutch.




- ④ Feed belt unit can be removed after bolts are removed.



Note.

After mounting the feed unit, ensure that the gap between clutches is  $0.25 \pm 0.1$  using a feeler gauge.



## 6. Adjustment

### 6- (1) Feed settings

#### (a) Blower

Standard Value

HOME	PRESET	MANUAL SET	FLEX MODE	MANUAL SPEED
<	>	VACUUM	5	▼ ▲
TABLE	▼ ▲	AIR ADJUST→	10	▼ ▲
CREASE 1	▼ ▲	AIR ADJUST↓	5	▼ ▲
D FEED HIGH	▶	SPEED	8	▼ ▲
LONG AIR BLOW	▶	Feed frequency	3	▼ ▲
CUTTER	ADJUST	PAPER FEED WORK TIME	1.000 s	

Input 10 in case paper is too heavy to feed.


There will be possibility of double feed if paper is too thin. In this case, input 5.

Ensure that LONG AIR BLOW is shown on the screen. There is possibility of empty feed.



(b) Aligner


- ① Check angle of aligner by position of a hole in below picture when attaching the feed belt unit.




- ② It is factory setting if Feed belt unit is attached so that a small hole contacts a big hole.

Hole position			
Status	<b>Default (FactorySetting)</b>	—	Parallel to Guide
Effectiveness of Aligner	High	Low	None



(c) Feed area mechanical adjustments  
(1) Lower Blower position



Note.  
Do not remove screws because blower will drop.






(2) Separator position



Separator must be placed on higher position than blower surface.


### (3) Feed belt unit position



#### (4) Feed sensor position


When the feed table is upper dead point, the proper gap between the feed table and the feed belt is  $2 \pm 0.5\text{mm}$  ( $0.08'' \pm 0.02''$ ).

Loosen the screws and adjust the position of the feed sensor properly.




## (5) Parallelism of basement



- ① In case that you detached the basement for the purpose of parts replacement etc., the basement can be attached parallel by pressing the base against Locating metal plate.  
(Ensure that the basement is put on Locating metal plate when you detach it)



- ② Please detach this part below in case that the upper surface of the basement is not parallel.




- ③ Settle a reference from two delivery rollers and adjust parallelism of the base with tolerance within 0.3 mm between A and B.




## 6- (2) Cut mark sensor

- ① Remove the sensor cover.
- ② Adjust the switch at "D" (D⇔L).
- ③ Turn the volume from "MIN" to "MAX" slowly without TEST MARK(Black).
- ④ As the volume is turned, green LED lights off, orange LED lights off, and green LED lights on again. Stop turning the volume at the position where green LED lights on.
- ⑤ Ensure that the orange LED lights when it senses the TEST MARK (Black) and the orange LED does not light when it senses the white part of the TEST MARK(Black). In addition to above, ensure that the green LED lights at all times. (If the green LED lights off sometime, the sensor may detect cut marks inconsistently.)



TEST MARK (Black)



Adjust it with a narrow Minus-head screwdriver.



### 6- (3) PCB setting




#### CPU Board

Subject	How to adjust
Origin Sensor	Turn VR3 fully in clockwise.
Stop Sensor	Turn VR4 fully in clockwise.
Double Feed Sensor	Turn VR2 on CPU Board fully in anticlockwise. Adjust VR1 on CPU Board with paper (126gsm) so that Double feed detection counter on Manual Operation Screen shows approximately 500. After this procedure, ensure that Double feed detection shows more than 40 with paper (350gsm). If this value is less than 40, adjust volume so that it shows more than 40.

#### I/O Board

Subject	How to adjust
Feed Sensor	Turn VR15 fully in clockwise.

#### CPUBoard




Double feed counter

## 6- (4) Accuracy adjustment

### (a) Length adjustment

- ① Regarding Length adjustment, refer to “5.5.2 If the cut measurement does not match the input value” in Operation Manual.
- ② Overwrite the initial setting value when you finished adjustment. .


ADJUST screen



Press and hold the bottom left corner of the screen for 3 seconds.




Enter the service password.




- ③ The values shown on the screen will be 0 after overwriting.  
The  $\times 1.000$  (length magnification) part will not become  $\times 1.000$  by press keeping 3 seconds at the bottom left corner (will not be stored internally).
- ④ If you prefer to reset values to factory settings, amend values shown on the Service Menu screen according to data which is attached inside of the front cover.  
(👉 Page12)


## 7. How to make layout

### 7- (1) General template(mm)






7- (2) General template(inch)





No.	Name of item	Qty.	materials
1	Feed table	1	SPCC 13.0
2	Touch panel	1	
3	Safety cover	1	SPCC 10.8
4	Card stacker	1	SPCC 11.6
5	Eject stacker	1	SPCC 10.8
6	Power switch	1	
7	Inlet	1	
8	Caster	4	Resin
9	Waste box	1	Resin



Mass of equipment: 200kg  
 Carton: W1220 x D1040 x H1290 255kg

revision	
△	..
△	..
△	..


Approval	Check	Design	Draw	Date
				2018. 2 .26
				Scale / . /

CE, UL / cUL


8- (1) Equipment, Electric circuit, and parts

8. Electricity related



BLOCK DIAGRAM (V1.00)  
AC100~120V



BLOCK DIAGRAM (V1.00)  
AC200~240V




# Electrical component



## 8- (2) Board Details

### ① CPU Board




### ② I / O Board







### ③ Wiring Details



### 8- (3) Input/Output LED Details




①LED on Lower Side



- D51 : OUTPUT- None
- D01 : OUTPUT- Cutter motor move forward
- D02 : OUTPUT- Cutter motor move reverse
- D06 : OUTPUT- None
- D08 : OUTPUT- None
- D09 : OUTPUT- None
- D10 : OUTPUT- None
- D16 : OUTPUT- None
- D17 : OUTPUT- None
- D38 : OUTPUT- None
- D19 : OUTPUT- None
- D21 : OUTPUT- None
- D39 : OUTPUT- Ionizer

② LED on Left Lower Side

D47 : OUTPUT- None	R159
D46 : OUTPUT- None	D47
D45 : OUTPUT- Clutch	D46
D43 : OUTPUT- Conveyor motor	D45
D41 : OUTPUT- Side Blow fan motor	D43
D36 : OUTPUT- Feed table move down	D41
D35 : OUTPUT- Feed table move up	D36
D31 : OUTPUT- Blow fan motor	D35
D30 : OUTPUT- None	D31
D29 : OUTPUT- None	D30
D27 : OUTPUT- Vacuum fan motor	D29
D25 : OUTPUT- Crease motor move reverse	D27
D23 : OUTPUT- Crease motor move forward	D25




③ LED on Left Upper Side

D48 : INPUT- None	R159
D40 : INPUT- None	D48
D24 : INPUT- Connect for Conveyor	D40
D42 : INPUT- Cutter upper limit switch	D24
D34 : INPUT- Feed table lower limit switch	D42
D26 : INPUT- None	D34
D11 : INPUT- None	D26
D04 : INPUT- None	D11
D62 : INPUT- Cover limit switch B	D04
D59 : INPUT- Cover limit switch A	D62
D56 : INPUT- None	D59
D52 : INPUT- None	D56
D44 : INPUT- None	D52
D37 : INPUT- Crease upper sensor	D44
D28 : INPUT- Crease lower sensor	D37
D13 : INPUT- Cut mark sensor	D28
D20 : INPUT- Stop sensor	D13
D03 : INPUT- Origin sensor	D20




④LED on Upper Side



### 8- (4) Tap Voltage Details

CPU BOARD



- TP1 : Power Supply for CPU
- TP2 : Power Supply for Touch Panel
- TP3 : Input from DC Power Supply
- TP4 : Power Supply for Pulse controller
- TP5 : Ground
- TP6 : Power Supply for Sensors and Control Systems
- TP7 : Ground
- TP8 : Power Supply for sensors and motor driver

TP6 +24 V  
TP7 GND

+3.3V LED  
(TP4-TP5)


TP4 +3.3V

+5 V LED  
(TP1-TP5)

TP2 +24 V  
TP3 +24 V  
TP5 GND

+24 V LED  
(TP2-TP5)

I/O BOARD




TP4 +24 V  
TP2 GND  
TP1 +24 V  
TP3 +24 V

TP6 GND  
TP5 +5 V

- TP1 : Power Supply for Motors
- TP2 : Ground
- TP3 : Power Supply for Sensors and Control Systems
- TP4 : Power Supply for None
- TP5 : Power Supply for Sensors and Motor driver
- TP6 : Ground

## 8- (5) Wiring Details






## 9. Program update

### 9- (1) Software install

#### (a) Requirements

	Transfer Tool	AVR STUDIO
Supported OS	Windows XP/VISTA/7/8/10	Windows XP/VISTA/7/8/10
CPU	Pentium IV 1 GHz processor or equivalent	Pentium 200 MHz processor or equivalent
Memory	1 GB or more	256 MB or more
Hard disk space	340 MB or more	100 MB or more
Display	1024 × 768 screen 16 bit high color or better	1024 × 768 screen (minimum 800 × 600 screen)
Interface	USB port	USB port

#### (b) Confirmation of Accessories



DISK1 will not be used for installation.

It contains files such as AVR-related instruction manuals.

Please refer to them when needed.





### (c) How to install Transfer Tool

Download the Transfer Tool Installer via below link.

[http://www.hmisoce.com/otasuke/en/download/freesoft/gpproex\\_transfer/v4/gpproex\\_transfer.htm](http://www.hmisoce.com/otasuke/en/download/freesoft/gpproex_transfer/v4/gpproex_transfer.htm)

(The procedure below is for WINDOWS 7)





Follow the dialogues to complete installation.

### (d) How to install AVR STUDIO

(The procedure below is for WINDOWS XP)



Double click on "AVR\_TOOL\AvrStudio4Setup.exe" of the CD/DVD.





Next is the update of AVR STUDIO.


Double click on “AVR\_TOOL¥AVRStudio4.18SP3.exe” of the CD/DVD.



Next is the installation of WINAVR.

Double click on “AVR\_TOOL¥ WinAVR-20100110-install -install.exe” of the CD/DVD.


① Select a language




② OK




③ Next




④ I Agree



⑤ Next



⑥ Install



⑦ Finish



⑧ × (Close the Window)



Next is the installation of win8\_10\_atmel\_driver.

If the OS of the PC is Windows 8 or 10, install this driver.

Double click on “win8\_10\_atmel\_driver¥ driver-atmel-bundle-7.0.888.exe” of the CD/DVD.



## 9- (2) Touch panel

### (a) Connecting to a computer / Transfer Tool operation

If any changes are made to the touch panel content, we will send the data to you most likely by e-mail.

The data format will look like "Morgana AutoCut\_V100.prx" with a file extension of ".prx". The figure "100" refers to a version, which means Version 1.00.

Save this data in a folder of your choice in your computer and upgrade the version as follows:

- ① Remove the unit cover, and connect the USB cable provided with the unit to the back of the touch panel as shown below. (The procedure below is for WINDOWS XP).




USB cable

- ② Turn on the power supply. If the installation of the USB driver is necessary at this point, install the driver using DISK2, which contains the driver in the USB folder.


- ③ Start up the computer and double click on




- ④ Click on Select Project.




- ⑤ Select the folder in which you saved our screen data, select a file with a file extension of prx.



- ⑥ Click on Send Project or .




- ⑦ Click Yes if a question, “Transfer change in system setting?” is asked. If the question is not asked, you do not need to do anything.






- ⑧ The touch panel will make a peep sound when the transmission has completed. Click Close.



- ⑨ After your installing updated software, the direction you can see the below will remain on the touch panel. After seeing that words on the screen, turn off the machine and turn it on again.




### 9- (3) CPU board

#### (a) AVRISP mk II connection and AVR STUDIO operation


If any changes are made to the program content, we will send the data to you most likely by e-mail.


The data format will look like "Morgana AutoCut\_V100.hex" with a file extension of ".hex" The figure "100" refers to a version, which means Version 1.00. Save this data in a folder of your choice in your computer and upgrade the version as follows:

- ① Remove the cover at the bottom of the front of the unit. Connect AVRISP mk II provided with the unit to CN7 of the CPU Board, and connect the USB cable to the computer.



- ② If the installation of the USB driver is necessary at this point, install the driver following the procedure below (The procedure below is for WINDOWS XP).







③ Start up the computer and double click on Start ⇒ Program ⇒ Atmel AVR Tools ⇒ AVR Studio 4.




④ Click on Cancel.



- ⑤ Click on AVR (Connect to the Selected AVR Programmer).




- ⑥ Select AVRISP mk II for Platform, Select USB for Port, click on Connect.



- ⑦ If the following warning appears on the screen, AVRISP mk II firmware upgrade is necessary. Click on OK. If the warning does not appear on the screen, skip to ⑩.




⑧ Click on Start Upgrade.





⑨ Disconnect the USB cable of AVRISP mk II and connect it again. After that, click on OK. If AVR STUDIO has shut down, return to ③ and conduct the operation again.




⑩ Click on Main tab, select the Atmega2560 for Device and Signature Bytes.



- ⑪ Click on Main tab and on Settings. Select 500 kHz for ISP Freq, click on Write, and click on Close.






- ⑫ After clicking on Program tab, select the folder where the file was initially saved as the save location. By clicking on Program, the transmission of the program will start. (About 30 sec.)



Select where our ".hex" file was initially saved.


- ⑬ Click the LockBits tab, and click ▼ next to “No memory lock features enabled,” then, select “Further programming and verification disabled.” Click “program”.



- ⑭ The process is completed when the transmission of the program has finished.
- ⑮ From the next time onward, proceed in the order of ③,④,⑤,⑩,⑫, and ⑬.


## 10. Cleaning & greasing

Do not remove these parts out of the machine when cleaning & greasing as regular maintenance.







Stop sensor





Slitter



Guillotine cutter



Roller






Creaser



C : Cleaning  
 O : Oiling  
 G : Greasing  
 Gp : Greasing for plastic



## 11. Recommended replacement parts




Parts name	Parts No.	Qty	Parts list
Slitter blade ASSY (Margin, upper)	7707-8001	2	Page 3
Slitter blade ASSY (Gutter, upper)	7707-8002	2	
Slitter blade ASSY (Lower)	7707-8003	6	
Paper feed belt	80-718	4	Page 13
Guillotine	61-045	1	Page 27
Carrying roller (Soft)	7703-0602	5	Page 37
Carrying roller (Hard)	7707-0601	1	
Carrying roller (Hard)	7703-7601	1	
Carrying roller (Hard) With black mark	7703-7602	2	
Carrying roller (Soft)	7703-0603	1	
Timing belt	82-541	1	
Timing belt	82-542	1	





## 12. Troubleshooting



<p>1</p>	<p>This occurs when the Safety cover or Stacker panel is opened.</p> <p>If the screen below remains after close the both cover.</p> 	<ul style="list-style-type: none"> <li>• Cover Sensor either A or B, or both may be out of order.</li> <li>☞ 3- (4) INPUT DATA CHECK Screen</li> <li>• The angle of the shield plate may be wrong.</li> <li>☞ 3- (4) INPUT DATA CHECK Screen</li> <li>• I/O Board may be out of order.</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul>
<p>2</p>	<p>This occurs when the unit was started with paper still remaining inside the unit.</p> <p>If the screen below remains after paper removal.</p> 	<ul style="list-style-type: none"> <li>• Either Origin Sensor, C/M Sensor, or Stop Sensor may be out of order.</li> <li>☞ 3- (4) INPUT DATA CHECK Screen</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul>
<p>3</p>	<p>This occurs when the paper did not pass through Origin Sensor at time of paper feeding.</p> <p>If this occurs frequently (except when there is no paper on Feed Table)</p> 	<p>When Feed Belt and Carrying Roller are both rotating:</p> <ul style="list-style-type: none"> <li>• Paper guides (Small) hold the sheets too tightly on the Feed table.</li> <li>• Paper tip could remain inside of the machine.</li> <li>• Clean feed belts.</li> <li>• Vacuum motor may be out of order.</li> <li>• Origin Sensor may be out of order.</li> <li>☞ 3- (4) INPUT DATA CHECK Screen</li> <li>• I/O Board may be out of order.</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul>

3		<p>When Feed Belt is not rotating:</p> <ul style="list-style-type: none"> <li>• Clutch may be out of order.</li> <li>• I/O Board may be out of order.</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul> <p>When Carrying roller is not rotating:</p> <ul style="list-style-type: none"> <li>• Servo Motor and/or Driver may be out of order.</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul>
4	<p>This occurs when the paper did not pass between Origin Sensor and Stop Sensor within a designated period of time. If this frequently occurs,</p> 	<p>When Carrying Roller is rotating:</p> <ul style="list-style-type: none"> <li>• Paper tip could remain inside of the machine.</li> <li>• Origin Sensor may be out of order. ☞ 3- (4) INPUT DATA CHECK Screen</li> <li>• Stop Sensor may be out of order. ☞ 3- (4) INPUT DATA CHECK Screen</li> <li>• Slipping is caused by powdered paper at Feed Roller.</li> <li>• Paper warpage may have occurred.</li> <li>• Slitter may be out of order.</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul> <p>When Carrying roller is not rotating:</p> <ul style="list-style-type: none"> <li>• Servo Motor and/or Driver may be out of order.</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul>



5	<p>This occurs when Feed Table is overloaded.</p> <p>If this occurs frequently,</p> <p>RETURN</p>  <p><b>MACHINE OVERLOAD!</b> <i>Please check paper feed table!</i></p>	<ul style="list-style-type: none"> <li>• Feed Motor may be out of order.</li> <li>• Switch (FD TBL UP/SENS, TBL LW/LMT SW) may be out of order.</li> <li>☞ 3- (4) INPUT DATA CHECK Screen</li> <li>• Screws of the coupling may be loose.</li> <li>• I/O Board may be out of order.</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul>
6	<p>This occurs when Cutter or Crease are overloaded.</p> <p>If this occurs frequently,</p> <p>RETURN</p>  <p><b>MACHINE OVERLOAD!</b> <i>Please check TRIMMER or CREASE UNIT.</i></p> <p>◀ ▶</p>	<p>When Cutter is overloaded:</p> <ul style="list-style-type: none"> <li>• Paper tip could remain inside of the machine.</li> <li>• Paper double feeding.</li> <li>• Paper thickness is out of specification.</li> <li>• Cutter blade may be blunt.</li> <li>• Cutter Motor may be out of order.</li> <li>• Switch (CUTTER UP/LMT SW) may be out of order.</li> <li>☞ 3- (4) INPUT DATA CHECK Screen</li> <li>• I/O Board may be out of order.</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul> <p>When Crease is overloaded:</p> <ul style="list-style-type: none"> <li>• Paper tip could remain inside of the machine.</li> <li>• Paper double feeding.</li> <li>• Paper thickness is out of specification.</li> <li>• Crease depth adjustment may be set incorrectly.</li> <li>• Crease Motor may be out of order.</li> <li>• Sensor (CRSR LW/SENS) may be out of order.</li> <li>☞ 3- (4) INPUT DATA CHECK Screen</li> <li>• I/O Board may be out of order.</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul>

7	<p>This occurs when Cut Mark could not be detected.</p> 	<ul style="list-style-type: none"> <li>• Cut Mark printing density needs to be checked.</li> <li>• Cut Mark Sensor needs to be re-adjusted.</li> <li>☞ 6- (2) Cut mark sensor</li> <li>• Cut Mark Sensor may be out of order.</li> <li>☞ 3- (4) INPUT DATA CHECK Screen</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul>
8	<p>Two or more sheets are fed at one time. If this occurs frequently,</p> 	<ul style="list-style-type: none"> <li>• Fan out the paper sufficiently and jog the paper to make the each of the sheets separately.</li> <li>• Adjust the volume of Blower Fan and Vacuum Fan.</li> <li>☞ 3- (3) SPEED Screen</li> <li>• Blow motor may be out of order.</li> </ul> <p>Note: Activate double-feed detection mode.</p> <p>☞ OPERATION MANUAL 「 5.1 Adjustments on the paper feed section」</p>
9	<p>This occurs when a servo error is detected. If this occurs frequently,</p> 	<ul style="list-style-type: none"> <li>• COVER SENS A, B may be out of order.</li> <li>☞ 3- (4) INPUT DATA CHECK Screen</li> <li>• Servo Motor Driver may be out of order.</li> <li>• Servo Motor may be out of order.</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul>

10	<p>This occurs at times of communication errors. If this occurs frequently,</p> 	<ul style="list-style-type: none"> <li>• Touch Panel may be out of order.</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul>
11	<p>This occurs at times that machine is operated when Cutter is not on top dead center. If this occurs frequently,</p> 	<ul style="list-style-type: none"> <li>• Switch (CUTTER UP/LMT SW) may be out of order.</li> <li>☞ 3- (4) INPUT DATA CHECK Screen</li> <li>• I/O Board may be out of order.</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul>
12	<p>This occurs at times that machine is operated when Cutter is not on bottom dead center. If this occurs frequently,</p> 	<ul style="list-style-type: none"> <li>• Sensor (CRSR UP/SENS) may be out of order.</li> <li>☞ 3- (4) INPUT DATA CHECK Screen</li> <li>• I/O Board may be out of order.</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul>
13	<p>This occurs when more sheets than set number has been delivered. If this occurs frequently,</p> 	<ul style="list-style-type: none"> <li>• Clutch may be out of order.</li> <li>• I/O Board may be out of order.</li> <li>• CPU Board may be out of order.</li> <li>• Wire breakage or connection failure may have occurred.</li> </ul>

14	<p>The dimensions of finished card are different from the measurements you have input.</p>	<ul style="list-style-type: none"> <li>Make it correct at ADJUST Screen.</li> </ul> <p>☞ OPERATION MANUAL 「5.6.2 If the cut measurement does not match the input value」</p>
15	<p>The lengths of finished cards are unequal.</p> 	<ul style="list-style-type: none"> <li>Clean Carrying rollers.</li> <li>Clean Sensors.</li> <li>Cutter blades could have got damaged and got partly dull. Replace the cutter unit.</li> </ul>
16	<p>The widths of finished cards are unequal.</p> 	<ul style="list-style-type: none"> <li>Clean Carrying rollers.</li> <li>Slitter blade could have got damaged and got partly dull.</li> <li>CPU Board may be out of order.</li> <li>Servo Motor Driver may be out of order.</li> <li>Servo Motor may be out of order.</li> </ul>
17	<p>Two or more sheets are fed at one time. If this occurs frequently,</p>	<ul style="list-style-type: none"> <li>Fan out the paper sufficiently and jog the paper to make the each of the sheets separately.</li> <li>Adjust the volume of Blower Fan and Vacuum Fan.</li> </ul> <p>☞ 3- (3) SPEED Screen</p> <ul style="list-style-type: none"> <li>Blow motor may be out of order.</li> </ul> <p>Note: Activate double-feed detection mode.</p> <p>☞ OPERATION MANUAL 「5.1 Adjustments on the paper feed section」</p>
18	<p>A sheet stops after moving slightly (with noise)</p>	<ul style="list-style-type: none"> <li>Thick paper cannot be fed at higher speed and a sheet stop being fed with noise.</li> </ul> <p>Please slow down the speed.</p>



19	Paper jam occurs frequently.	<ul style="list-style-type: none"> <li>▪ Paper curl too much to be conveyed smoothly.</li> <li>▪ The dimensions of the paper are different from the measurements you input into the machine.</li> <li>▪ Paper tip could remain inside of the machine.</li> </ul> <p>(Origin sensor, Slitter, Cutter, Creaser)</p>
20	Paper remains at a Crease blade.	<ul style="list-style-type: none"> <li>▪ Make Crease depth smaller.</li> </ul> <p> OPERATION MANUAL 「5.5 Creaser adjustment」</p>
21	The movement of slitter block is not smooth.	<p>Please adjust slitter head.</p> <p> Page. 26</p>

# Factory setting

DIST BTW KNF & CRSR	<input type="text"/>	CUTTER	<input type="text"/>
DIST BTW SENS2 & KNF	<input type="text"/>	CREASE	<input type="text"/>
DIST BTW SENS1 & C/MAR	<input type="text"/>	COUNT	<input type="text"/>
DIST BTW SENS1 & KNF	<input type="text"/>	TABLE	<input type="text"/>
D FEED CHECK	<input type="text" value="20"/>		
PAPER FEED WORK TIME	<input type="text" value="1.000"/>	<input type="text"/>	<input type="text" value="RETURN"/>

78-819 V1.00