

FD 8300HS High Security Shredder

> MAINTENANCE MANUAL SECOND EDITION

TABLE OF CONTENTS

TOPIC	PAGE
Specifications	1
Set-up Guidelines	1
Control Panel	1
Operation	2
Safety Devices and Other Features	2
Safety Precautions	3
Daily Maintenance	3
Auto Cleaning	3
Sensor Sensitivity Recovery	4
Removing Motor & Cutting Head Unit	4
Replacing Door Hinges	5
Replacing Casters	5
Repairing Motor Condenser & Contact	5
Troubleshooting	6-7
Parts Lists	8-10
Electrical Parts	11-12

Specifications

Cutting Style:	Cross Cut		
Shred Size:	1/32" x 3/16" (Level 6)		
Sheet Capacity:	7 to 8 sheets*		
1-Hour NSA Durability Test:	6 reams / feeding 3 sheets		
Speed:	18 fpm		
Feed Opening:	9.5"		
Dimensions:	18" W x 19" D x 26" H		
Bin Capacity:	15 gal.		
Weight:	149 lbs.		
Power Supply:	110V, 50/60 Hz		
 * Capacity varies depending on paper and power supply * No staples or paper clips 			




Set-up Guidelines

1. Install the shredder on a level surface, away from heat sources and direct sunlight.

2. Insert plug into wall outlet with the appropriate voltage, 110V. If the outlet is shared with another electronic device, the total current should not exceed 30A (at 110V).

Control Panel Functions



AUTO: The shredder will operate in Auto mode after pressing the Start button.

MANUAL: By pressing the Start button a second time, the shredder can be operated in Manual mode. The shredder will begin running, and will stop automatically after 3 minutes.

STOP: Pressing this button stops operation.

REV: The shredder will automatically reverse cutter direction if too many sheets of paper are inserted at one time.

FULL: The shredder automatically stops when the waste bin is full.

OPEN: The shredder will stop automatically if the cabinet door is open. Simply close the door and press Start to resume operation.

LOAD INDICATOR: This multi-colored indicator shows the load during shredding.

Control Panel

Operation

1. Open the door and turn the circuit breaker switch to "ON" (see page 12). Close door. Flip ON/OFF button (right side of cabinet, see page 3) to "ON".

2. Auto Start/Auto Stop

Press the "START" button. The signal lamp "AUTO" will light. Insert paper to shred. The shredder will start and stop automatically when using this function.

3. Manual Operation

If paper is too small for the shredder's sensors to detect, shred it manually. Push the "START" button once more and the "MANUAL" lamp will light. Insert paper to be shredded. Three minutes after shredding, the cutter automatically stops rotating.

4. Reverse Operation

Push the "REV" button. The signal lamp "REV" will light and cutters will operate in reverse. If too much paper is inserted at one time in standard modes, the shredder will automatically operate in reverse. If this occurs, remove the inserted paper and shred in smaller amounts. NOTE: The maximum amount of paper to be shredded differs according to paper quality, humidity and voltage. If the shredder is to be used continuously, do not insert more than half of the maximum capacity.

5. Full Sensor

If the waste bin is full, the "FULL" lamp will light and the cutter will stop automatically. Open the door, empty the waste bin of paper shreds, replace the waste bin, close door, press "START" and continue to shred.

Safety Devices & Other Features

Automatic Reverse Rotation

When too much paper is inserted, the cutter stops operating and automatically rotates in reverse to discharge the jammed paper. An alarm sounds. Reduce the amount of paper and restart the operation.

Door Switch

If the door is open, the shredder will not operate.

Automatic Stop

When the waste bin is full of shredded material, the "FULL" light comes on and the cutter stops operation. Open the door, remove the waste bin and empty paper scraps. Replace the waste bin, close the door and continue operation.

Automatic Power Shut-Off

If the shredder operates continuously for more than 30 minutes, the power is automatically shut off.
If the motor is overloaded, the "STOP" LED will flash until it cools down. When the flashing stops the shredder is ready to be used again.

Oil Indicator

Oil regularly for peak performance. NOTE: High Security shredders require a specialized oil that can only be ordered through Formax, part # 8000-15. The "MANUAL" LED will flash after every four (4) hours of operation as an indicator to oil the shredder cutting blades. The LED will continue to flash until oiled. NOTE: the shedder will still operate when the LED is flashing but at a decreased load capacity.

To oil: Spread shredder oil onto the cutters through the feed opening, and allow the oil to sit for a few minutes to permeate the cutting blades, then press the "REV" button and hold for five seconds. "MANUAL" and "REV" LED indicators on control panel will light. The shredder will operate in reverse for one minute, then the "AUTO" LED will light indicating the shredder is ready.

Safety Precautions

To avoid personal injury, and damage to the shredder, observe the following safety precautions. Please keep these instructions for future reference.

NOTE: In case of emergency, push the ON/OFF button on the right side, or pull the plug out of the wall outlet.

• Keep hands, long hair, clothing, ties, jewelry and other loose items away from the paper entrance.

• Do not use the shredder for anything other than its intended purpose. Never use it to shred cloth, plastic, cardboard or any hard material that will cause damage to the shredder blades. **DO NOT SHRED STAPLES OR PAPER CLIPS.**

- Do not allow children to use the machine.
- Do not operate with a damaged power cord or plug, or when the machine is damaged in any manner.
- Unplug the shredder when it is being moved, or if it is not in use for an extended period of time.
- Do not disconnect the power by pulling only the cord. Hold the plug when disconnecting.
- Keep the shredder away from direct sunlight.
- Do not sit on the shredder or place anything on top of it.
- Never open the fixed switch or cover.

Daily Maintenance

- Disconnect power by pulling power cord plug from wall outlet.
- To clean the exterior, wipe the surface with a soft cloth. If the surface is very dirty, use a neutral detergent, then wipe again with a soft cloth.

CAUTION:

- Never put water directly on the surface of the shredder.
- Never clean the case with benzene or thinner, since it will cause discoloration.
- Do not dismantle the shredder. Contact your Formax Dealer for service.

Auto Cleaning Function

Use the Auto Cleaning function when sheet capacity is decreased.

1. Prior to using the Auto Cleaning function, spread shredder oil onto the cutters through the shred opening, and allow the oil to sit for a few minutes to permeate the cutting blades.

- 2. Press the REV button and hold for five seconds. Manual and Rev LED indicators on control panel will light.
- 3. The shredder will operate in reverse for one minute, then the Auto LED will light.



Sensor Sensitivity Recovery Function

Over time, the shredder photo eye may lose its sensitivity. Use the following steps to reset the sensor's sensitivity.

- 1. If the sensor cannot detect paper:
 - Press the Stop button for five seconds.
- 2. If the shredder is operating without paper in the feed opening:
 - Press stop, then insert paper into the feed opening and press the Stop button for five seconds.

After following either of these steps, all LED lamps should be off, and the shredder will make a beep sound. Sensitivity is recovered and the shredder is ready to operate. Follow instructions under Operation.

Removing Motor & Cutting Head Unit

To remove the motor and cutting head unit for servicing:

- Turn off circuit breaker and ON/OFF switches. Unplug power cable from wall.
- Open front door, remove screws connecting lid to body case.
- Unplug cables and remove lid; set aside.
- Remove waste bin; set aside.
- Using a 12mm socket, remove four nuts on under side (see Figure 1).
- Carefully lift out motor/cutting head unit from the top. CAUTION: Heavy.



Figure 1

Replacing Door Hinges

If the door is separated from the body housing, replace the upper and/or lower hinge (Figures 2 and 3).




Figure 2, top hinge




Figure 3, bottom hinge

Replacing Casters

If casters are damaged, remove rivets and attach new casters with screw bolts (Figure 4).




Figure 4, caster

Repairing Motor Condenser & Contact

If the motor doesn't work, the motor condenser or motor current contact could be damaged. Open the motor cover, clean the contact and adjust the gap of contact.

Alternately, replace the motor condenser (see page 9).




TROUBLESHOOTING

PROBLEM:	CHECK THIS:	SOLUTION:
Shredder will not operate	Check that the power cord is plugged into an appropriate outlet	Plug cord into outlet
	Check voltage of power outlet	If necessary, find an alternate outlet with the appropriate voltage
	Check the wiring between the fuse connector on the PCB (page 12)	Reconnect, if necessary
Shredder capacity is de- creased		Follow directions for Auto Cleaning, page 3
Main power is functioning but shredder won't operate (Main PCB)	Check main power cable (page 11) to see if it is properly connected to the Main PCB (page 12)	Reconnect, if necessary
	Check the Main PCB's printed circuit and wire disconnection of transformer	If there is a problem with the circuit and/ or transformer, replace with new one
	Check the electrical contacts on the main control switch	Reconnect, if necessary
Main power is okay, but shredder is not working (electrical) NOTE: Photo sensor should be connected with the main PCB during testing.	Check the outlet for correct voltage, 120V	Use different outlet, if necessary
	Check wire connection between photo sensor and Main PCB (pages 11 & 12). If there is no output signal from Main PCB, shredder will not operate.	Reconnect cable to sensor and Main PCB
	Photo sensor could be dirty	Remove photo sensor (page 11) and clean it with a soft cloth
	Photo sensor sensitivity may need to be reset	Sensitivity measurement distance should be .4 inch (10mm). If distance is less than .4 inch, replace the photo sensor
	Check power relay contacts	Reconnect, or replace main PCB power relay if necessary. If printed circuit is damaged, replace the main PCB.
Main power is okay, but shredder is not working	Check motor current contact	Open motor cover, clean contact and adjust gap of contact (page 5)
(mechanical)	Shredder may have overheated.	Wait 5-10 minutes for motor to cool down, then resume shredding
	Check motor condenser for damage	Replace motor condenser


Chradder mater and blades	Charle control nanal lights to say if	If an follow instructions for Conser
Shredder motor and blades continue to rotate	Check control panel lights to see if AUTO lamp is flashing	If so, follow instructions for Sensor Sensitivity Recovery on page 4.
	Check control panel lights to see if MANUAL lamp is on	If yes, press the START button. AUTO lamp should light and shredder should operate in AUTO mode.
	Photo sensor could be dirty	Remove photo sensor (page 11) and clean it with a soft cloth.
	Photo sensor sensitivity may need to be reset	Sensitivity measurement distance should be .4 inch (10mm). If distance is less than .4 inch, replace the photo sensor.
	Check power relay contacts	Reconnect, or replace main PCB power relay if necessary.
Reverse function will not work	Check power relay contacts (in case of electrical coil damage)	Replace power relay.
	Check printed circuit for damage	If damaged, replace the Main PCB.
Shredder makes an unusual or metallic noise	Check cutters for materials lodged between cutting blades and/or guides	If so, turn off shredder and carefully remove any foreign materials from the cutter. Then follow instructions for Auto Cleaning (page 3).
	Check guides and cutters for dam- age (page 9)	If guides and/or cutters are broken, the whole cutting head should be replaced
	Check bearings, space rings and cutting shafts for damage (page 9)	If any of these parts are damaged, they should be replaced, in addition to side plates
Motor makes a "tick tick" noise	Check the reduction gears for dam- age (page 5)	If the reduction gears are broken, replace the entire motor


PARTS LISTS




ITEM	PART #	DESCRIPTION	QTY
1	8300HS-CAS-01	TOP CASE	1
2	8300HS-CAS-04	BODY CASE	1
3	8300HS-CAS-05	UPPER DOOR HINGE	1
4	8300HS-CAS-06	LOWER DOOR HINGE	1
5	8300HS-CAS-09	DOOR	1
6	8300HS-CAS-10	DOOR MAGNET	1
7	8300HS-CAS-07	FRONT COVER PLATE	1
8	WST-AA-0006	WASTE BIN	1
9	8300HS-PCB-08	MICRO SWITCH, DOOR, 15A	1
10	8300HS-CAS-01	CASTERS	4
11	8300HS-PCB-16	MAIN POWER SWITCH	1


MECHANICAL PARTS







ITEM	PART #	DESCRIPTION	QTY
1	8300HS-CUT-02	MOTOR, 400W	1
2	8300HS-CUT-05	SPUR GEAR (m=2, z=31)	1
3	8300HS-CUT-06	SPUR GEAR (m=2, z=31)	1
4	8300HS-CUT-04	MAIN SPUR GEAR (m=1.5, z=71)	1
5	8300HS-CUT-03	MOTOR GEAR (m=1.5, z=71)	1
6	8300HS-PCB-06	CIRCUIT BREAKER, 15A	1
7	8300HS-PCB-08	MICRO SWITCH (DOOR), 15A	1
8	8300HS-PCB-15	MOTOR CONDENSER	1
9	8300HS-CUT-08	SIDE PLATE, LEFT	1
10	8300HS-CUT-09	SIDE PLATE, RIGHT	1
11	8300HS-CUT-10	POST	2
12	8300HS-CUT-11	FRONT WASTEPROOF PLATE	1
13	8300HS-CUT-12	MIDDLE PLATE	1
14	8300HS-CUT-13	SHAFT (LONG)	1
15	8300HS-CUT-14	SHAFT (SHORT)	1
16	8300HS-CUT-15	CUTTER BLADE	-
17	8300HS-CUT-16	GUIDE	-
18	8300HS-CUT-17	RING	-
19	8300HS-CUT-18	BEARING (6005ZZ)	-
20	8300HS-CUT-19	ACETAL RING (3.0t)	-
21	8300HS-CUT-20	ACETAL RING (5.0t)	-
22	8300HS-PCB-01	MAIN PCB	1
23	8300HS-PCB-03	PCB CASE	1
23	8300HS-CUT-07	VIBRATION PROOF RUBBER (025)	4
24	8300HS-PCB-10	BODY CABLE	1
-	8300HS-CUT-00	CUTTING HEAD WITH MOTOR	-
-	8300HS-CUT-01	CUTTING HEAD WITHOUT MOTOR	-











Top View

ITEM	PART #	DESCRIPTION	QTY
1	8300HS-CUT-07	VIBRATION-PROOF RUBBER (025)	4
2	8300HS-CAS-08	WASTE BIN FULL SENSOR PLATE	1
3	8300HS-PCB-07	MICRO SWITCH (WASTE BIN)	1

ELECTRICAL PARTS





ITEM	PART #	DESCRIPTION	QTY
1	8300HS-PCB-02	SWITCH PCB	1
2	8300HS-PCB-05	PHOTO SENSOR	1
3	8300HS-PCB-09	SENSOR CABLE	1
4	8300HS-PCB-14	POWER PLUG	1
5	8300HS-CAS-03	SWITCH COVER	1
6	8300HS-PCB-04	PCB SUPPORTERS (JOSS-6N)	4
7	8300HS-CAS-02	TOP CASE (INNER)	1





`1













ITEM	PART #	DESCRIPTION	QTY
1	8300HS-PCB-01	MAIN PCB	1
2	8300HS-PCB-06	CIRCUIT BREAKER, 15A	1
3	8300HS-PCB-08	MICRO SWITCH (DOOR), 15A	1
4	8300HS-PCB-11	MAIN CABLE	1
5	8300HS-PCB-12	DATA OUTPUT CABLE	1
6	8300HS-TRA-01	TRANSFORMER	1
7	8300HS-FIL-01	NOISE FILTER	1
8	8300HS-PCB-13	DOOR OPEN CABLE	1